


130 mm

95.00 mm

英文通用说明书玻璃壶三个壶20210401



Features

- 1、 Compact appearance: elegant style. fashion. & save space.
- 2、 convenient :a 360-degree rotation(series), split-type design. built-in water level mark. use in--friendly.
- 3、 Safety and health: three ways of electrical product safety system
 - a、 Boil water after cut off the power automatically
 - b、 Water dry after cut off the power to protect
 - c、 Cut off the power automatically to prevent overheating;

Before use, please note the following

- 1、 Make sure that the rated voltage accomplish with our product parameter uasge.
- 2、 Must a grounded power supply into the outlet.
- 3、 Although the product have dry bolling protection device, aim for the extension of life. avoid to dry boil.
- 4、 Do not let children touch the product and pull the power cord to avoid burns, electric shock
- 5、 Do not put near to the fire source, flammable goods, and oven.
- 6、 Put boliled water away in the first time usage.

Use Method

- 1、 Place the Kettle on the flat surface.
- 2、 Remove the kettle from the base, insert water not less than the minimum water level or exceed the maximum line.
- 3、 Put the kettle on the power outlet and connect to the base.
- 4、 Press the switch, indicator light, Kettle begin to boil water.
- 5、 The water boiled off when automatically cut off the power, the Indicator light turns off.
- 6、 You can turn off the power at any time.
- 7、 Automatically cut off the power and then re-switch it but necessary to wait 15-20 seconds, so that the cooling temperature sensor unit in order to re-open.

Clean and maintenance

- 1、 Clean before alloction of plug Remove from the base, fliter, use of oil or soft detergent to clean the outer surface in order to maintain (To avoid the use of invasive and friction cleaning)
- 2、 Avoid dipped in water to clean. prevent water erosion thermostat and plug.
- 3、 In case effect of water quality, water will be naturally occurring process in result of accumulated calcium oxide. Cleaning must be condructed in regular.

Simple maintenance

- 1、 Loaded half water and also adding 30 milliliters of white vinegar. Stir 30 seconds after the special static, so repeat after a night can be placed (for example, need to repeat this process in case of serous)
- 2、 Don't use any metal or hard objects to clean up hot plate. otherwise it will create scratches.
- 3、 Do no place or get the sun exposure on the barbecue fire.

How to check the problem

- *If the kettle can't be worked on normal, please note the following.
 - 1. May damage the power cord (should replace by technical person)
 - 2. May be loose plug
 - 3. May not switch on the power
 - 4. Heat burned the body.

After Service

- 1. In accordance of normal condition operating, if it is failure, please contact the seller where you buy from is responsible for after service.
- 2. scope of non-warranty
 - *Without purchase invoice
 - *Product damage caused by errors
 - *Arising from failure of repair
 - *Damage caused by natural disasters or man-made

Technical Parameters

Implementation of standards. GB4706. 1-2005
GB4706. 19-2008
Continuously updated as a result of products. we preserve the right to change technical parameter without notice.